

Translations:ASKotec Tutorials - DIY Simple analog synth/13/en

1. Take each basic component and put it onto the marked place (You might need to use some tape to hold the elements in place)
2. Check, if + of LED is on the shown side
3. Solder each part on the board...DO NOT CUT THE LEGS, WE NEED IT!!!
4. Bend the legs like it is shown in the second image