

Translations:ASKotec Tutorials - DIY Simple analog synth/16/en

1. Cut the overlapping part of the leg shown in the picture
2. Bend the piece like an wide U, and put it into the place at the potentiometer
3. Solder the U to bridge the channels