

# Translations:ASKotec Tutorials - DIY Simple analog synth/22/en

---

- Solder the wire as shown
- Using this prototype board, you will need to connect wires to the soldered elements directly
- Compare the schematic with the photos to see which pins need to be connected
- Be careful not to bridge other pins accidentally