

# Translations:ASKotec Tutorials - DIY Simple analog synth/26/en

---

Here you need to take of a bigger piece of the wires isolation, so you can then use it to get to the jack sockets ground pin on the other side. Check the second image