

Translations:Analogic Drawing Pad/30/en

We now need to create a support for the pen. Use a piece of cardboard to create it, then glue it to the other piece of cardboard hosting the skewers.