

Translations:ASKotec Tutorials - DIY Simple analog synth/37/en

1. Cut off the middle leg of the Transistor SS9018HBU TO-92, and plug it into the socket left 1st and 3rd
2. Plug in the first capacitor into the socket right, with + in the 1st and - in the 4th
3. Plug in an audio cable to an amplified speaker, or laptop
4. Connect the battery