

Translations:Analogic Drawing Pad/27/en

Use some hot glue to stick the ends of the skewers to the nylon wire