

## **Translations:Robot "ABC" en bois/54/en**

---

Take 4 screws M4 insert them in the 4 holes then fix 1 nut on each screws.