

Translations:Spinning Kinetic Sculpture RGB/80/en

To make it works: Hold the back wheel still. Spin the front wheel clockwise, few turns are enough but don't turn more than 20 times(check the tape on the spring). If you come to unwind the spring from the external pulley you'll have to place it back manually by opening the sculpture, be careful.