## Translations:Pet that lights up upon interaction/45/en

If you click on Serial Monitor (top right of the Arduino IDE screen, below the "X" button), you should see the values recorded by the touch sensor.