# **Connected weather station**

In this tutorial you will learn how to set up a weather station based on ESP32, and how to monitor its readings remotely, via the Blynk app as well as via a website.



Matériaux

#### Outils

### Étape 1 - Wiring up the components

Connect the sensors as follows: Light sensor One end to 3V the other end to the 10kohm resistor which in turn is connected to GND. the same end of the LDR is also connected to pin D34 on the ESP32 CJMCU CCS811  $3V \rightarrow 3V$  on the ESP32 board  $GND \rightarrow GND$   $SDA \rightarrow D21$  pin on ESP32  $SCL \rightarrow D22$  pin on ESP32  $VCL \rightarrow GND$ DHT11  $GND \rightarrow GND$  on ESP32  $VCC \rightarrow 3V$  on ESP32

## Étape 2 - Program the ESP32 board

Launch Arduino IDE.

Select your ESP32 board from the Tools menu.

Make sure you've also selected the correct Port.

Upload <u>this</u> code on to the board.

If you open the serial monitor (set the baud rate to 9600), you should be able to view the values recorded by the different sensors.

💿 display_LDR_value_on_blynk   Arduino 1.8.3						
File Edit Sketch Tools Help						
display_LDR_v	Auto Format Archive Sketch Fix Encoding & Reload	Ctrl+T				
<pre>#include <wif #include="" <bly<="" <wif="" pre=""></wif></pre>	Serial Monitor Serial Plotter	Ctrl+Shift+M Ctrl+Shift+L				
<pre>char auth[] =</pre>	WiFi101 Firmware Updater Blynk: Check for updates Blynk: Example Builder					
5	Blynk: Run USB script		3(			
no ve or Diecimila	Board: "DOIT ESP32 DEVKIT VI Flash Frequency: "80MHz" Upload Speed: "921600"	• • •				
1ega or Mega 2560	Core Debug Level: "None" Port Get Board Info	k k	ut 1c r			
тн	Programmer: "AVRISP mkII" Burn Bootloader	۶.				

File Edit Sketch Too	ols Help					
display LDR V	Auto Format Archive Sketch	Ctrl+T				
<pre>#include <wif #include="" <bly<="" <wif="" pre=""></wif></pre>	Serial Monitor Serial Plotter	Ctrl+Shift+M Ctrl+Shift+L	Γ			
<pre>char auth[] = char ssid[] = char pass[] = const int ana int sensorVal BlynkTimer ti void setup() Serial.begi</pre>	WiFi101 Firmware Updater					
	Blynk: Check for updates Blynk: Example Builder					
	Blynk: Run USB script Board: "DOIT ESP32 DEVKIT V1"	' I	36)			
	Flash Frequency: "80MHz"					
	Core Debug Level: "None"	1		at 0600 boa:		
Blynk.begin	Port: "COM4"			Serial ports		
timer.setIn	Get Board Info			COM3		
Done Saving.	Programmer: "AVRISP mkII" Burn Bootloader	1		COIM4		

#### oo COM4

```
le taux de coz est de : 446 ppm
connection to server failed
le CO est de : 4095
la temperature est de : 28
l'humidité est de : 47
il y a 1 lux
le taux de co2 est de : 400 ppm
connection to server failed
le CO est de : 4095
la temperature est de : 28
l'humidité est de : 47
il y a 1 lux
le taux de co2 est de : 400 ppm
connection to server failed
le CO est de : 4095
la temperature est de : 28
l'humidité est de : 47
il y a 1 lux
le taux de co2 est de : 400 ppm
connection to server failed
le CO est de : 4095
la temperature est de : 28
l'humidité est de : 47
il y a 1 lux
le taux de co2 est de : 400 ppm
connection to server failed
le CO est de : 4095
la temperature est de : 28
l'humidité est de : 47
il y a 1 lux
le taux de co2 est de : 400 ppm
connection to server failed
le CO est de : 4095
la temperature est de : 28
l'humidité est de : 47
il y a 1 lux
le taux de co2 est de : 400 ppm
connection to server failed
 Autoscroll
```

The result of the local division of the loca

## Étape 3 - Monitor the weather station remotely via Blynk App

Blynk app enables us to monitor the values recorded by the weather station remotely, directly on our smartphone, regardless our distance from the weather station.

All we need is the blynk app and an internet connection. In this project you'll learn how to monitor the values recorded by the LDR sensor and the DHT11 sensor only.

#### Create a new project in the Blynk app

After you've download the app and you've successfully logged into your account, start by creating a new project.

#### Choose Your Hardware

Select the hardware model you will use. If you are following this tutorial you II probably be using an ESP32 board.

#### Auth Token

Auth Token is a unique identifier which is needed to connect your hardware to your smartphone. Every new project you create will have its own Auth Token. You'll get Auth Token automatically on your email after project creation. You can also copy it manually. Click on devices section and selected required device:

And you'll see token :

#### Set up the Blynk app

You will need to create a project on blynk which is tailored for the purpose of monitoring the parameters recorded by the weather station. Grab 3 value display widgets.

Configure them one by one. The first will receive V6 as input, the second V5 and the third V0. You II notice that they re all set to push mode.



21:56 12	1.78K/s 🖇 🖄 🛜 📶 🗩	) 13:48 🗧 🗋 🖨 🕴 0.02K/s 🖇 🞯 奈 📶 ナー		
÷	Project Settings	← My Devices		
New Project		Device Name		
SHARED AC	CESS	HARDWARE MODEL		
	OFF ON	ESP8266		
	Generate Link			
	4 <b>1000</b>	WiFi		
	How it Works	AUTH TOKEN		
DEVICES		f064daa6f6a7411ebe591f796f2e6a17		
<b>M</b>	New Device ESP8266 + WiFi	Refresh E-mail		
KEEP SCRE	EN ALWAYS ON			
	OFF ON	Create		



## Étape 4 - Program the ESP32 board

Launch arduino IDE and open  $\underline{this}$  program.

Select the board you re using from the Tools menu, as well as the correct Port.

Upload the code.

If upload is successful, you should be able to see a message from Blynk on the serial monitor.



[3706] Connecting to blynk-cloud.com:80
[3808] Ready (ping: 20ms).

## Notes et références

## List of parts

1x ESP32 board + usb power cable 1x DHT11 sensor 1x light sensor 1x 10 Kohm resistor 1x CJMCU CCS811 sensor several jumper wires a number of breadboards or a PCB (if you decide to do some soldering) female headers (if you decide to do the soldering).